

USER'S MANUAL



WARNING

THIS WARNING REFERS TO A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT CORRECTED, COULD RESULT IN DEATH OR SERIOUS INJURY.

- YOU MUST ABSOLUTELY WEAR AN APPROVED LIFEJACKET.
- THIS IS NOT LIFE-SAVING EQUIPMENT.
- THIS ITEM IS NOT A TOY AND SHOULD NOT BE USED BY CHILDREN UNDER 16 YEARS OF AGE OR BY CHILDREN WITHOUT ADULT SUPERVISION. CONSULT YOUR STATE OR LOCAL REGULATIONS.
- USE THIS BOAT ONLY ON CALM WATER. DO NOT USE IN STRONG WINDS OR FAST CURRENTS.

SAFETY INSTRUCTIONS

- . NEVER USE ALONE.
- NEVER USE THIS BOAT IN BAD WEATHER.
- KEEP SHARP OBJECTS (KNIVES, HOOKS, ETC.) AWAY FROM THE TUBES.
- DO NOT USE UNDER THE INFLUENCE OF DRUGS OR ALCOHOL.
- DO NOT TOW THIS FLOAT TUBE IF SOMEONE IS SITTING INSIDE.
- GET OUT OF THE WATER IN CASE OF THUNDERSTORM AND RISK OF LIGHTNING.
- DO NOT USE CO2 OR HIGH PRESSURE COMPRESSOR TO INFLATE.
- FOLLOW THE INFLATION STEPS IN THIS MANUAL.
- · CHECK FOR LEAKS BEFORE USE.
- REMEMBER THAT AIR PRESSURE CHANGES WITH TEMPERATURE AND ALTITUDE, SO ALWAYS CHECK THE AIR PRESSURE BEFORE USE. THIS MANUAL LISTS RECOMMENDED PRACTICES AND PROVIDES BASIC PRECAUTIONS. HOWEVER, THIS LIST OF PRECAUTIONS DOES NOT COVER ALL RISKS. USERS MUST COMPLY WITH ALL LAWS, RULES AND REGULATIONS AND ARE REQUIRED TO EXERCISE CAUTION WHEN USING THIS PRODUCT. AT SEA, BE SURE TO SAIL CLOSE TO SHORE AND NOT MORE THAN 300 METERS FROM A SHELTER. REMEMBER -ALWAYS USE COMMON SENSE WHEN USING YOUR FLOAT TUBE.







LIST OF ITEMS SUPPLIED WITH THE AMTRAC FISHING STORM:

ATTENTION: THE 3 PIECES OF FOAM CONTAINED IN THE FLOAT TUBE BOX ARE NEEDED FOR THE SEAT

- 1 FLOAT TUBE
- 1 SEAT
- 1 FOOT PUMP
- 1 STRIPPING APRON
 1 SPACED BAR IN A RIF
- 1 SPACER BAR IN 2 PIECES
 1PAIR OF CARRYING STRAPS
- 1 REPAIR KIT CONTAINING 2 PVC PATCHES AND GLUE



INFLATION AND ASSEMBLY OF THE FLOAT TUBE:

- 1) PLACE THE FLOAT TUBE FLAT ON THE FLOOR WITH THE VALVES FACING UPWARDS.
- 2) INFLATE THE FLOAT TUBE TO A MAXIMUM PRESSURE OF 0.8 BAR
- 3) INFLATE THE SEAT TO A MAXIMUM PRESSURE OF 0.8 BAR
- 4) JOIN THE TWO PIECES OF THE SPREADER BAR BY PLACING BOTH ENDS ANGLED OUTWARD.
- **5)** INSERT THE SPREADER BAR INTO THE ENVELOPE OF THE RECEIVING MAT AND PLACE IT IN THE TWO LOCATIONS AT THE ENDS OF THE BLADDERS.

CARE AND STORAGE OF THE FLOAT TUBE

IT IS IMPORTANT TO RINSE YOUR FLOAT TUBE THOROUGHLY WITH CLEAN WATER AFTER EACH USE. ALWAYS ENSURE THAT THE BLADDERS ARE PARTIALLY DEFLATED BEFORE STORING THE ASSEMBLED FLOAT TUBE IN A WARM VEHICLE OR ROOM. THE AIR INSIDE THE INNER TUBES CAN EXPAND CONSIDERABLY. IF THE FLOAT TUBE WILL NOT BE USED FOR AN EXTENDED PERIOD OF TIME, DEFLATE IT AND STORE IT. TO PREVENT MOULD GROWTH, MAKE SURE THE FLOAT TUBE IS DRY BEFORE PACKAGING AND STORE IT IN A DRY PLACE.

GETTING IN THE WATER:

- 1. START ON A SLIGHT SLOPE (SUCH AS A BOAT RAMP).
- 2. PUT YOUR FINS ON AND THEN PUT THE FLOAT TUBE IN THE WATER (IDEALLY THE WATER SHOULD REACH YOUR KNEES). TAKE A SEAT ON BOARD BY ENTERING FROM THE OPEN SIDE AND THEN TURN SO THAT YOUR BACK IS FACING THE BACK OF THE SEAT.
- 3. SIT ON BOARD THE FLOAT TUBE, HOOK THE LANDING MAT BACK ON AND LET YOURSELF FLOAT AWAY. PRACTISE USING YOUR FINS TO BACK UP AND TURN.



GARANTEE

- 1. THE WARRANTY IS VALID FROM THE DATE OF PURCHASE.
- 2. THE WARRANTY IS VALID ONLY IF THIS PRODUCT IS FOR PERSONAL USE ONLY.
- 3. AMTRAC FISHING WILL MAKE THE FINAL DECISION REGARDING THE WARRANTY, WHICH MAY REQUIRE INSPECTION AND/OR PHOTOS OF THE EQUIPMENT THAT CLEARLY PROVE THE DEFECT(S). IF NECESSARY, THIS DOCUMENT SHOULD BE SENT TO THE DEALER IN YOUR COUNTRY AT THE OWNER'S EXPENSE. THE PRODUCT CAN ONLY BE RETURNED IF THE AMTRAC FISHING DEALER HAS GIVEN A RETURN AUTHORIZATION NUMBER. THIS MUST BE VISIBLE ON THE OUTSIDE OF THE PACKAGE OR IT WILL BE REFUSED.
- **4.** IF A PRODUCT IS FOUND TO BE DEFECTIVE BY AMTRAC FISHING, THE WARRANTY COVERS REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT ONLY. AMTRAC FISHING WILL NOT BE RESPONSIBLE FOR ANY COSTS, LOSS OR DAMAGE INCURRED AS A RESULT OF LOSS OR MISUSE OF THE PRODUCT.
- 5. THIS WARRANTY DOES NOT COVER DAMAGE CAUSED BY MISUSE, ABUSE, NEGLECT, NORMAL WEAR AND TEAR. SIMILARLY, IT IS NOT LIMITED TO PUNCTURES, DAMAGE DUE TO EXPOSURE TO EXCESSIVE HEAT, DAMAGE CAUSED BY IMPROPER HANDLING OR STORAGE, AND DAMAGE NOT RELATED TO THE INTRINSIC QUALITY OF THE MATERIAL AND WORKMANSHIP.
- 6. THIS PRODUCT MUST NOT BE MODIFIED AND/OR EQUIPPED WITH A MOTOR.
- 7. THIS PRODUCT SHOULD NOT BE USED BEYOND THE RECOMMENDED MAXIMUM LOAD CAPACITIES.
- 8. THIS WARRANTY IS VOID IF AN UNAUTHORIZED REPAIR HAS BEEN MADE, OR IF ANY PART OF THE FLOAT TUBE HAS BEEN CHANGED OR
- 9. THE WARRANTY FOR ALL REPLACEMENT EQUIPMENT IS EFFECTIVE FROM THE DATE OF PURCHASE.
- **10.** THE ORIGINAL RECEIPT OF PURCHASE MUST BE ENCLOSED FOR ALL WARRANTY CLAIMS. THE NAME OF THE RETAILER AND THE DATE OF PURCHASE MUST BE CLEAR AND LEGIBLE.
- 11. NO WARRANTY WILL EXTEND BEYOND THE WARRANTY SPECIFIED HEREIN.
- 12. WARRANTY IS NOT INHERITABLE. IT CANNOT BE TRANSFERRED BETWEEN OWNERS.